

ZelHer[®] P30



USER GUIDE

ZelHer P30

Thank you for choosing the ZelHer P30 Bluetooth headset, please examine the contents of the package to ensure that you have received all items, please read the entire full user guide before using the headset

PACKAGE CONTENTS


- P30 Bluetooth headset
- AC charger
- Car charger
- USB Cable
- User Guide

User Guide for P30

KEY SPECIFICATIONS

- Bluetooth v3.0
- 24 Hours: Talk Time
- 750 Hours: Standby time
- Enhanced Battery Saver (EBS) Extending battery live up to 8 months
- Working Range: 32ft
- Multipoint Support: (Pair and keeps connections with 2 Bluetooth devices)
- Balanced and Lite Weight
- Fits Comfortably on Either Ear
- Supporting profiles: Headset Profile (HP), Hand-Free Profile (HFP), Advanced Audio Distribution Profile (A2DP).

ABOUT YOUR ZELHER P30



- 1** Volume Up
Volume Down
- 2** Multifunction Button
- 3** Indicator LED
- 4** USB Charge slot

GETTING STARTED

- It is important to fully charge the headset, before starting the pairing process before initial use.
- Recommended Initial charge time is 3-5 hours.
- Do not use the headset while charging.

Note:

- If you do not use your headset for a long period of time, it is recommended to recharge the headset for at least 3-5 hours before resuming use.
- Recharge unit in places at room temperature between 41°F (5°C) and 104°F (40°C).

CHARGING THE HEADSET

To Charge the unit:

1. Connect the large end of the USB cable into charger port.
2. Connect the small end of the USB cable into headset charging port.
3. Plug the charger into a proper outlet.
4. While charging, the indicator light on headset will turn red, when charging is complete; the indicator light will change to blue, flashing once every 10 seconds.

Turning on:

Press and hold the Multi-function button (MFB) for 3-5 seconds, the blue light indicator will flash 3 times, and you will hear a voice prompt saying “Hello”.

Turning off:

Press and hold the MFB for 3-5 seconds; the red light indicator will flash 3 times, and you will hear a voice prompt saying “Good bye”.

PAIRING THE HEADSET:**Pairing to 1 device**

1. Press and hold the MFB for approximately 6-8

seconds, until the LED light alternates between red and blue, you will hear a voice prompt saying “pairing” indicating that it is in pairing mode.

2. Activate the Bluetooth search feature on your phone; refer to your phone’s manual for further instructions.

3. Select the P30 from the list of devices detected on your phone or computer.

4. If necessary enter pin code 0000 and accept connection.

5. When pairing is complete, your phone will prompt

you to connect to the headset enter “Connect” or “Yes”.

6. When connected you will hear a voice prompt saying “your device is connected” and the LED will flash blue indicating that your Bluetooth headset is connected to your phone.

Pairing a 2nd Device:

1. Pair the first phone following the steps above.
2. Temporarily turn off the first connected phone’s Bluetooth wireless technology function.

3. Pair the second phone using the steps above.
4. Turn off the headset, and once again turn on the first phone's Bluetooth wireless technology functionality.
5. Once again turn on the headset, and it will reconnect to both devices automatically.

GENERAL FUNCTIONS:

Turning on:

Press and hold the MFB for 3-5 seconds; the blue light indicator will flash 3 times and you will hear a voice prompt saying "Hallo". The headset will automatically attempt to connect with the last device to which it was

paired. Once connected, you will hear a voice prompt saying “your device is connected”, and the blue light will blink once every 10 seconds.

Turning off:

Press and hold the MFB for 3-5 seconds; the red light indicator will flash 3 times and you will hear a voice prompt saying “good bye”.

Whenever your Bluetooth gets disconnected from other Bluetooth devices, a voice prompt will say “your device is disconnected”.

When Bluetooth gets disconnected, the Enhanced

battery saver (EBS) mode will automatically turn on.

Adjust the volume:

Press Volume + or – while on a call or streaming audio.

Incoming call / Ending a call:

Simply Press the MFB once.

Reject a call:

Press and hold MFB for 3 seconds.

Redial:

Press the MFB twice.

Voice Dialing:

Press the MFB for 2 seconds.

Voice dial feature will use the last paired device, for example if you pair device A and device B the voice dial will jump to device B

Mute On/Off:

Press and hold volume (-) for 2-3 seconds.

You will hear a double beep every 15 sec. while your Bluetooth is on mute.

Wearing the Headset:

This headset can be worn on either ear and can be

adjusted according to your preference and comfortably.
To minimize tightness from headband use the headset extenders.

Low Battery Warning:

When battery will reach to only 10% of power, the indicator light will begin to blink red and you will hear a voice prompt saying “low battery” every 30 seconds.

Enhanced Battery Saver (EBS):

Extending battery live up to 8 months

When Bluetooth power is on without being connected to any paired Bluetooth device, the blue light will start

to blink twice every 5-6 seconds for approximately 10 minutes, signaling that device will automatically turn off after 10 minutes of not getting any paired Bluetooth connection.

Keep your Battery alive:

- For ideal charge capacity and extended battery life, do not overcharge your Bluetooth headset; wait until you get the Low battery warning signal.
- Make sure to keep this product within the recommended temperature range of -4°F (-20°C) and 104°F (40°C).

Getting out of 32 feet distance:

When your Bluetooth headset gets out of the 32 feet distance from your other Bluetooth device, you will hear a double beep every 10 seconds signaling that you are out of the 32 ft. range, after 10 minutes of being out of range, your device will automatically revert to EBS mode.

Headset Storage:

- Only use original accessories with this device.
- Do not disassemble headset, it will void the warranty.
- Store headset away from dust, heat, and water.

- Use clean, soft, static free cloth to clean headset surfaces.
- Do not allow children to play or use headset.
- Do not store headset or charger in extreme environments.

Fifth Avenue Accessories Corp. Limited Warranty

All Zelher Bluetooth headsets carry a one year limited warranty, from date of purchase.

Fifth Avenue Accessories Corp. Warrants this headset will be free from defects in materials and workmanship for a period of one year from the date of purchase.

During the first year, we will at our option, repair or replace this product or any defective parts, free of charge. Consumable components subject to normal wear and tear, such as microphone windscreens, ear cushions are not included in this one-year warranty.

We recommend that you keep the original shipping materials, as it is important that the product will not be damaged during shipping.

To obtain Warranty Service, please contact us at warranty@zelher.com or by calling 866.783.4546.

The following information must be presented to obtain Warranty Service, (1) Proof of purchase, which clearly indicates the name of the dealer, the product type, the date of purchase, name and address of purchaser, (2) the Bluetooth headset.

Consumer will be responsible for shipping or transportation charges to us.

Products returned to **Fifth Avenue Accessories Corp.** For repair under this warranty will be return shipped to the customer at our expense.

The warranty does not cover damage caused by accident, direct and indirect, misuse or abuse, neglect, improper operation, unauthorized product modification or repairs, or any cause other than defects in the materials or workmanship of **Fifth Avenue Accessories Corp.**'s products.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc.

Fifth Avenue Accessories Corp.

P O BOX 1002,
Harriman, NY 10926

P. 866.783.4546
www.zelher.com
info@zelher.com